

Модель	Наименование	Цена, \$
<b>FireStore [ FS-4 / FS-5 / FS-C / FS-CV / FS-100 ] FS Портативные дисковые рекордеры</b>		
<b>FS-4 [ для SD/HD камер S, P, C, J ]*: **</b>		
ASYF-1346-01LF	<b>FS-4 HD 80 GB Euro</b>	995
ASYF-1163-01LF	<b>FS-4 ProHD 60GB Euro</b>	1 240
ASYF-1167-01LF	<b>FS-4 ProHD 80GB Euro</b>	1 695
ASYF-1171-01LF	<b>FS-4 ProHD 100GB Euro</b>	1 900
<b>FS-C [ для SD/HD камер S, P, C ]*: **</b>		
ASYF-1051-01	<b>FS-C 60GB Euro</b>	1 495
ASYF-1052-01	<b>FS-C 100GB Euro</b>	2 095
<b>FS-100 [ для SD/HD камер P ]*: **</b>		
ASYF-1275-01LF	<b>FS-100 160GB Euro</b>	1 595
ASYF-1297-01LF	<b>FS-100 250GB Euro</b>	2 095
<b>FS-5 [ для SD/HD камер S, P, C, J ]*: ** - NEW !! MXF &amp; MetaData support + Wi-Fi + USB 2.0</b>		
ASYF-1320-01LF	<b>FS-5 60GB Euro</b>	1 895
ASYF-1311-01LF	<b>FS-5 100GB Euro</b>	2 295
<b>FS-CV [ для SD/HD (XL/XH) камер C ]*: ** - NEW !! MXF &amp; MetaData support + Wi-Fi + USB 2.0</b>		
ASYF-1333-01LF	<b>FS-CV 100GB Euro</b>	2 295
<b>Media Converters MC-HD1 и MCSDI-1</b>		
ASYF-1395-01LF	<b>MC-HD1 Universal Media Converter - Euro</b>	5 100
ASYF-1268-01LF	<b>MCSDI-1 SD/HD Analog to SD/HD SDI portable Converter</b>	730
* Sony - [S]; Panasonic - [P]; Canon - [C]; JVC - [J]		
** Точный перечень сертифицированных камер смотри на вложенной странице "Поддерживаемые камеры"		
<b>Аксессуары FS-4 / FS-5 / FS-C / FS-CV / FS-100 / DR-HD100 ]</b>		
<b>Аккумуляторы</b>		
ASYF-1039-01	<b>FS-4/DR-HD100/FS-C/FS-100 Extra Battery 90 min.</b>	150
ASYF-1040-01	<b>FS-4/DR-HD100/FS-C/FS-100 High Capacity Battery 180 min.</b>	225
ASYF-1323-01LF	<b>FS-5/FS-CV Standard Battery (3-hour)</b>	175
<b>Чехлы</b>		
VZ00061	<b>FS-4/ FS-C/ FS-100 / DR-HD100 Bag</b>	77
<b>Зарядные устройства</b>		
ASYF-0941-01LF	<b>External FS-4/FS-100/DR-HD100 Battery Charger Euro</b>	197
VZ00051	<b>Power Pack FS-4/FS-100/DR-HD100 (Charger + 180 Min Batterie)</b>	345
<b>Крепления</b>		
ASYF-1044-01	<b>FS-4/FS-100/DR-HD100 Camera Mount Kit (Hot-Shoe Swivel Mount, Cradle for 90/180 Minute Battery, 6-4-Pin FireWire Cable 12")</b>	152
ASYF-1043-01	<b>FS-4/FS-100/DR-HD100 Cradle only (for 90/180 Minute Battery)</b>	49
ASYF-1057-01	<b>FS-C Cradle for Canon XL-H2 (incl. screw)</b>	135
ASYF-1325-01LF	<b>FS-5/FS-CV Camera Handle Mount Cradle</b>	155
ASYF-AB0001-01	<b>Camera Mount Kit for Shouldercameras with Anton Bauer Battery System</b>	515
ASYF-IDX001-01	<b>Camera Mount Kit for Shouldercameras with IDX Battery System</b>	590
VZ00058	<b>Bebob Box-FS</b>	357
<b>Блоки питания</b>		
PWRS-038-03	<b>FS-4/DR-HD/FS-100 Power Supply Euro (220V)</b>	43
<b>Кабели, клипсы, пульт управления</b>		
ACSS-0022-01	<b>FS-4/FS-100/DR-HD100 Replacement Belt Clip</b>	19
CBLA-0113-01	<b>FS-2/-3/-4/FS-100/DR-HD100 Serial Cable (RS-232C)</b>	49
ACSS-0019-01	<b>FS-2/-3/-4/FS-100/DR-HD100 Wired Remote Control</b>	77
ASYS-0482-01	<b>FS-4/FS-100 6 to 4 pin Firewire Cable 12"</b>	45
CBLA-0151-01LF	<b>FS-4/FS-100 4 pin, right angle to 6 pin FireWire Cable 48"</b>	45
ASYS-0483-01	<b>FS-4/FS-100 6 to 4 pin Firewire Cable 36"</b>	45
CBLA-0122-01	<b>FS-4/FS-100 6 to 6 pin Right Angle Firewire Cable 16"</b>	45
CBLA-0164-01LF	<b>FS-5/FS-CV 4-6 pin Slim Firewire Cable 24"</b>	45
CBLA-0165-01LF	<b>FS-5/FS-CV 6-6 pin Slim Firewire Cable 24"</b>	45
CBLA-0166-01LF	<b>FS-5 USB2.0 A-A Cable 36"</b>	45
ASYF-1343-01LF	<b>FS-5/FS-CV WIFI DONGLE 802.11 US, EURO, UK</b>	82