

MODULAR SUSPENSION		
<u>AKG</u>		
40101	Small Modular Suspension for AKG CK91/ CK92/CK93 + SE 300B	269
40101	Small Modular Suspension for AKG CK 451/ CK 460	269
40101	Small Modular Suspension for AKG CK61 C460B	269
40101	Small Modular Suspension for AKG CK63 460	269
40101	Small Modular Suspension for AKG D130	269
40103	Medium Modular Suspension for AKG C568EB	288
40103	Medium Modular Suspension for AKG CK68 ULS C460B RED	288
40103	Medium Modular Suspension for AKG CK98 SE300B	288
40103	Medium Modular Suspension for AKG CK8 451/CK8 460	288
40103	Medium Modular Suspension for AKG CK68 ULS C460B	288
<u>Audio Technica</u>		
40101	Small Modular Suspension for Audio Technica AT822	269
40101	Small Modular Suspension for Audio Technica AT825	269
40103	Medium Modular Suspension for Audio Technica AT4073	288
40103	Medium Modular Suspension for Audio Technica AT835ST	288
40103	Medium Modular Suspension for Audio Technica AT877	288
40103	Medium Modular Suspension for Audio Technica AT 835b/AT815(ST)	288

40103	Medium Modular Suspension for Audio Technica AT 897	288
40103	Medium Modular Suspension for Audio Technica AT4071a	288
40105	Large Modular Suspension for Audio Technica AT815b	299
40105	Large Modular Suspension for Audio Technica AT4071AL	299
AZDEN		
40103	Medium Modular Suspension for Azden SG(M)-1X	288
40103	Medium Modular Suspension for Azden SG(M)-2X (Cardiod capsule)	288
Beyer		
40101	Small Modular Suspension for Beyer M160	269
40101	Small Modular Suspension for Beyer M88	269
40101	Small Modular Suspension for Beyer M201	269
40101	Small Modular Suspension for Beyer MC 713/723	269
40101	Small Modular Suspension for Beyer M69	269
40101	Small Modular Suspension for Beyer MC718/728	269
40103	Medium Modular Suspension for Beyer MCE 87vs	288
40103	Medium Modular Suspension for Beyer MC836	288
40103	Medium Modular Suspension for Beyer M58	288
40103	Medium Modular Suspension for Beyer MC716/726	288
40103	Medium Modular Suspension for Beyer MC736	288
40103	Medium Modular Suspension for Beyer MCE 86 N (C) S	288
40105	Large Modular Suspension for Beyer MC837	299
40105	Large Modular Suspension for Beyer MC717/ MC727	299

40105	Large Modular Suspension for Beyer MC737	299
<u>Neumann</u>		
40101	Small Modular Suspension for Neumann KM100	269
40101	Small Modular Suspension for Neumann KM 184	269
40101	Small Modular Suspension for Neumann KM100F	269
40102	Small (30) Modular Suspension for Neumann RSM191	269
40103	Medium Modular Suspension for Neumann KMR 81	288
40103	Medium Modular Suspension for Neumann KMR 82	288
<u>Pearl</u>		
40102	Small (30) Modular Suspension for Pearl MS 2/ MS8 / MSH10	269
<u>Pode</u>		
40104	Medium (30) Modular Suspension for Rode NT4	288
<u>Sanken</u>		
40101	Small Modular Suspension for Sanken CMS-2/ CMS-7	269
40103	Medium Modular Suspension for Sanken CMS-9	288
40103	Medium Modular Suspension for Sanken CS-3	288
40105	Large Modular Suspension for Sanken CSS-5	299
<u>Schoeps</u>		
40101	Small Modular Suspension for Schoeps CMC Series	269
40101	Small Modular Suspension for Schoeps CMC Series + CUT 1	269
40106	Mono Extended Suspension for Schoeps CCM CCM41/9COMPACT MIC)	256

40106	Mono Extended Suspension for Schoeps CMC MK41 (REMOTE CAPSULE)	256
<u>Sennheiser</u>		
40101	Small Modular Suspension for Sennheiser MKH 20, 40, 50 , 406	269
40101	Small Modular Suspension for Sennheiser MKH 30, ME62 K6, MKE 44P	269
40103	Medium Modular Suspension for Sennheiser MKH 416, 418	288
40103	Medium Modular Suspension for Sennheiser MKH 60	288
40103	Medium Modular Suspension for Sennheiser ME66 K6	288
40103	Medium Modular Suspension for Sennheiser ME80 K3U	288
40103	Medium Modular Suspension for Sennheiser MKH 70	288
40103	Medium Modular Suspension for Sennheiser ME67 K6	288
40105	Large Modular Suspension for Sennheiser MKH 816	299
40101	Small Modular Suspension for Sennheiser ME64 K6	269
<u>Shure</u>		
40101	Small Modular Suspension for Shure SM 81	269
40105	Large Modular Suspension for Shure SM89	299
<u>Sony</u>		
40101	Small Modular Suspension for Sony ECM 959	269
40101	Small Modular Suspension for Sony ECM-MS5	269
40103	Medium Modular Suspension for Sony ECM-670	288
40104	Medium (30) Modular Suspension for Sony ECM 979	288
40103	Medium Modular Suspension for Sony ECM 999	288

40103	Medium Modular Suspension for Sony ECM-672	288
40105	Large Modular Suspension for Sony C-74	299
40105	Large Modular Suspension for Sony C-76	299
WINDSHIELD (BODY)		
AKG		
10602	Windshield 2 for AKG CK91/CK92/CK93 + SE 300B	246
10602	Windshield 2 for AKG CK 451/CK 460	246
10603	Windshield 3 for AKG CK61 C460B	246
10603	Windshield 3 for AKG CK63 460	246
10603	Windshield 3 for AKG D130	246
10604	Windshield 4 for AKG C568EB	261
10604	Windshield 4 (less ext1) for AKG CK68 ULS C460B RED	261
10604	Windshield 4 (less ext1) for AKG CK98 SE300B	261
10604	Windshield 4 (less ext 2) for AKG CK8 451/CK8 460	261
10604	Windshield 4 (less ext 3) for AKG CK68 ULS C460B	261
Audio Technica		
10603	Windshield 3 for Audio Technica AT822	246
10603	Windshield 3 for Audio Technica AT825	246
10604	Windshield 4 for Audio Technica AT4073	261
10604	Windshield 4 for Audio Technica AT835ST	261
10604	Windshield 4 for Audio Technica AT877	261
10604	Windshield 4 (less ext 2) for Audio Technica AT 835b/AT815(ST)	261
10604	Windshield 4 for Audio Technica AT 897	261
10604	Windshield 4 (less ext 2) for Audio Technica AT4071a	261
10604	Windshield 4 (less ext 3) for Audio Technica AT815b	261

10604	Windshield 4 (less ext 4) for Audio Technica AT4071AL	261
<u>Azden</u>		
10604	Windshield 4 for Azden SG(M)-1X	261
10604	Windshield 4 (less ext 2) for Azden SG(M)-2X (Cardiod capsule)	261
<u>Beyer</u>		
10602	Windshield 2 for Beyer M160	246
10602	Windshield 2 for Beyer M88	246
10602	Windshield 2 for Beyer M201	246
10602	Windshield 2 for Beyer MC 713/723	246
10603	Windshield 3 for Beyer M69	246
10603	Windshield 3 for Beyer MC718/728	246
10604	Windshield 4 for Beyer MCE 87vs	261
10604	Windshield 4 for Beyer MC836	261
10604	Windshield 4 for Beyer M58	261
10604	Windshield 4 for Beyer MC716/726	261
10604	Windshield 4 (less ext 1) for Beyer MC736	261
10604	Windshield 4 (less ext 1) for Beyer MCE 86 N (C) S	261
10604	Windshield 4 (less ext 4) for Beyer MC837	261
10604	Windshield 4 (less ext 4) for Beyer MC717/ MC727	261
10604	Windshield 4 (less ext 4) for Beyer MC737	261
<u>Neumann</u>		
10601	Windshield 1 for Neumann KM100	246
10601	Windshield 1 for Neumann KM 184	246
10601	Windshield 1 for Neumann KM100F	246
10603	Windshield 3 for Neumann RSM191	246
10604	Windshield 4 for Neumann KMR 81	261
10604	Windshield 4 (less ext 2) for Neumann KMR 82	261
<u>Pearl</u>		
10603	Windshield 3 for Pearl MS 2/MS8 / MSN10	246
<u>Pode</u>		
10604	Windshield 4 for Rode NT4	261
<u>Sanken</u>		

10603	Windshield 3 for Sanken CMS-2/CMS-7	246
10604	Windshield 4 for Sanken CMS-9	261
10604	Windshield 4 for Sanken CS-3	261
10604	Windshield 4 (less ext 1) for Sanken CSS-5	261
<u>Schoeps</u>		
10602	Windshield 2 for Schoeps CMC Series	246
10603	Windshield 3 for Schoeps CMC Series + CUT 1	246
10605	Windshield AA for Schoeps CCM CCM41/9COMPACT MIC)	235
10605	Windshield AA for Schoeps CMC MK41 (REMOTE CAPSULE)	235
<u>Sennheiser</u>		
10602	Windshield 2 for Sennheiser MKH 20, 40, 50 , 406	246
10603	Windshield 3 for Sennheiser MKH 30, ME62 K6, MKE 44P	246
10604	Windshield 4 for Sennheiser MKH 416, 418	261
10604	Windshield 4 for Sennheiser MKH 60	261
10604	Windshield 4 (less ext 1) for Sennheiser ME66 K6	261
10604	Windshield 4 (less ext 1) for Sennheiser ME80 K3U	261
10604	Windshield 4 (less ext 2) for Sennheiser MKH 70	261
10604	Windshield 4 (less ext 3) for Sennheiser ME67 K6	261
10604	Windshield 4 (less ext 4) for Sennheiser MKH 816	261
10603	Windshield 3 for Sennheiser ME64 K6	246
<u>Shure</u>		
10603	Windshield 3 for Shure SM 81	246
10604	Windshield 4 (less ext 4) for Shure SM89	261
<u>Sony</u>		
10603	Windshield 3 for Sony ECM 959	246
10603	Windshield 3 for Sony ECM-MS5	246
10604	Windshield 4 for Sony ECM-670	261

10604	Windshield 4 for Sony ECM 979	261
10604	Windshield 4 for Sony ECM 999	261
10604	Windshield 4 (less ext 1) for Sony ECM-672	261
10604	Windshield 4 (less ext 3) for Sony C-74	261
Special	Special Windshield for Sony C-76	
WINDSHIELD (Extension)		
10701	Extension 1	64
10702	Extension 2	68
10703	Extension 3	75
10704	Extension 4	81
WINDJAMMER		
AKG		
21502	Windjammer 2 for AKG CK91/CK92/CK93 + SE 300B	165
21502	Windjammer 2 for AKG CK 451/CK 460	165
21503	Windjammer 3 for AKG CK61 C460B	165
21503	Windjammer 3 for AKG CK63 460	165
21503	Windjammer 3 for AKG D130	165
21504	Windjammer 4 for AKG C568EB	171
21505	Windjammer 5 for AKG CK68 ULS C460B RED	171
21505	Windjammer 5 for AKG CK98 SE300B	171
21506	Windjammer 6 for AKG CK8 451/CK8 460	171
21507	Windjammer 7 for AKG CK68 ULS C460B	184
Audio Technica		
21503	Windjammer 3 for Audio Technica AT822	165
21503	Windjammer 3 for Audio Technica AT825	165
21504	Windjammer 4 for Audio Technica AT4073	171
21504	Windjammer 4 for Audio Technica AT835ST	171
21504	Windjammer 4 for Audio Technica AT877	171

21506	Windjammer 6 for Audio Technica AT 835b/AT815(ST)	171
21504	Windjammer 4 for Audio Technica AT 897	171
21506	Windjammer 6 for Audio Technica AT4071a	171
21507	Windjammer 7 for Audio Technica AT815b	184
21508	Windjammer 8 for Audio Technica AT4071AL	184
<u>Azden</u>		
21504	Windjammer 4 for Azden SG(M)-1X	171
21506	Windjammer 6 for Azden SG(M)-2X (Cardiod capsule)	171
<u>Beyer</u>		
21502	Windjammer 2 for Beyer M160	165
21502	Windjammer 2 for Beyer M88	165
21502	Windjammer 2 for Beyer M201	165
21502	Windjammer 2 for Beyer MC 713/723	165
21503	Windjammer 3 for Beyer M69	165
21503	Windjammer 3 for Beyer MC718/728	165
21504	Windjammer 4 for Beyer MCE 87vs	171
21504	Windjammer 4 for Beyer MC836	171
21504	Windjammer 4 for Beyer M58	171
21504	Windjammer 4 for Beyer MC716/726	171
21505	Windjammer 5 for Beyer MC736	171
21505	Windjammer 5 for Beyer MCE 86 N (C) S	171
21508	Windjammer 8 for Beyer MC837	184
21508	Windjammer 8 for Beyer MC717/MC727	184
21508	Windjammer 8 for Beyer MC737	184
<u>Neumann</u>		
21501	Windjammer 1 for Neumann KM100	165
21501	Windjammer 1 for Neumann KM 184	165
21501	WindjammerWindshield 1 for Neumann KM100F	165
21503	Windjammer 3 for Neumann RSM191	165
21504	Windjammer 4 for Neumann KMR 81	171
21506	Windjammer 6 for Neumann KMR 82	171
<u>Pearl</u>		

21503	Windjammer 3 for Pearl MS 2/MS8 / MSH10	165
<u>Pode</u>		
21504	Windjammer 4 for Rode NT4	171
<u>Sanken</u>		
21503	Windjammer 3 for Sanken CMS-2/CMS-7	165
21504	Windjammer 4 for Sanken CMS-9	171
21504	Windjammer 4 for Sanken CS-3	171
21505	Windjammer 5 for Sanken CSS-5	171
<u>Schoeps</u>		
21502	Windjammer 2 for Schoeps CMC Series	165
21503	Windjammer 3 for Schoeps CMC Series + CUT 1	165
21509	Windjammer AA for Schoeps CCM CCM41/9COMPACT MIC)	132
21509	Windjammer AA for Schoeps CMC MK41 (REMOTE CAPSULE)	132
<u>Sennheiser</u>		
21502	Windjammer 2 for Sennheiser MKH 20, 40, 50 , 406	165
21503	Windjammer 3 for Sennheiser MKH 30, ME62 K6, MKE 44P	165
21504	Windjammer 4 for Sennheiser MKH 416, 418	171
21504	Windjammer 4 for Sennheiser MKH 60	171
21505	Windjammer 5 for Sennheiser ME66 K6	171
21505	Windjammer 5 for Sennheiser ME80 K3U	171
21506	Windjammer 6 for Sennheiser MKH 70	171
21507	Windjammer 7 for Sennheiser ME67 K6	184
21508	Windjammer 8 for Sennheiser MKH 816	184
21503	Windjammer 3 for Sennheiser ME64 K6	165
<u>Shure</u>		
21503	Windjammer 3 for Shure SM 81	165
21508	Windjammer 8 for Shure SM89	184
<u>Sony</u>		
21503	Windjammer 3 for Sony ECM 959	165
21503	Windjammer 3 for Sony ECM-MS5	165

21504	Windjammer 4 for Sony ECM-670	171
21504	Windjammer 4 for Sony ECM 979	171
21504	Windjammer 4 for Sony ECM 999	171
21505	Windjammer 5 for Sony ECM-672	171
21507	Windjammer 7 for Sony C-74	184
Special	Special Windjammer for Sony C-76	
HI WIND COVER		
<u>AKG</u>		
22502	Hi Wind Cover 2 for AKG CK91/CK92/CK93 + SE 300B	66
22502	Hi Wind Cover 2 for AKG CK 451/CK 460	66
22503	Hi Wind Cover 3 for AKG CK61 C460B	66
22503	Hi Wind Cover 3 for AKG CK63 460	66
22503	Hi Wind Cover 3 for AKG D130	66
22504	Hi Wind Cover 4 for AKG C568EB	68
22505	Hi Wind Cover 5 for AKG CK68 ULS C460B RED	68
22505	Hi Wind Cover 5 for AKG CK98 SE300B	68
22506	Hi Wind Cover 6 for AKG CK8 451/CK8 460	68
22507	Hi Wind Cover 7 for AKG CK68 ULS C460B	77
<u>Audio Technica</u>		
22503	Hi Wind Cover 3 for Audio Technica AT822	66
22503	Hi Wind Cover 3 for Audio Technica AT825	66
22504	Hi Wind Cover 4 for Audio Technica AT4073	68
22504	Hi Wind Cover 4 for Audio Technica AT835ST	68
22504	Hi Wind Cover 4 for Audio Technica AT877	68
22506	Hi Wind Cover 6 for Audio Technica AT 835b/ AT815(ST)	68
22504	Hi Wind Cover 4 for Audio Technica AT 897	68
22506	Hi Wind Cover 6 for Audio Technica AT4071a	68

22507	Hi Wind Cover 7 for Audio Technica AT815b	77
22508	Hi Wind Cover 8 for Audio Technica AT4071AL	77
<u>Azden</u>		
22504	Hi Wind Cover 4 for Azden SG(M)-1X	68
22506	Hi Wind Cover 6 for Azden SG(M)-2X (Cardiod capsule)	68
<u>Beyer</u>		
22502	Hi Wind Cover 2 for Beyer M160	66
22502	Hi Wind Cover 2 for Beyer M88	66
22502	Hi Wind Cover 2 for Beyer M201	66
22502	Hi Wind Cover 2 for Beyer MC 713/723	66
22503	Hi Wind Cover 3 for Beyer M69	66
22503	Hi Wind Cover 3 for Beyer MC718/728	66
22504	Hi Wind Cover 4 for Beyer MCE 87vs	68
22504	Hi Wind Cover 4 for Beyer MC836	68
22504	Hi Wind Cover 4 for Beyer M58	68
22504	Hi Wind Cover 4 for Beyer MC716/726	68
22505	Hi Wind Cover 5 for Beyer MC736	68
22505	Hi Wind Cover 5 for Beyer MCE 86 N (C) S	68
22508	Hi Wind Cover 8 for Beyer MC837	77
22508	Hi Wind Cover 8 for Beyer MC717/MC727	77
22508	Hi Wind Cover 8 for Beyer MC737	77
<u>Neumann</u>		
22501	Hi Wind Cover 1 for Neumann KM100	66
22501	Hi Wind Cover 1 for Neumann KM 184	66
22501	Hi Wind Cover Windshield 1 for Neumann KM100F	66
22503	Hi Wind Cover 3 for Neumann RSM191	66
22504	Hi Wind Cover 4 for Neumann KMR 81	68
22506	Hi Wind Cover 6 for Neumann KMR 82	68
<u>Pearl</u>		
22503	Hi Wind Cover 3 for Pearl MS 2/MS8 / MSH10	66

<u>Pode</u>		
22504	Hi Wind Cover 4 for Rode NT4	68
<u>Sanken</u>		
22503	Hi Wind Cover 3 for Sanken CMS-2/CMS-7	66
22504	Hi Wind Cover 4 for Sanken CMS-9	68
22504	Hi Wind Cover 4 for Sanken CS-3	68
22505	Hi Wind Cover 5 for Sanken CSS-5	68
<u>Schoeps</u>		
22502	Hi Wind Cover 2 for Schoeps CMC Series	66
22503	Hi Wind Cover 3 for Schoeps CMC Series + CUT 1	66
22509	Hi Wind Cover AA for Schoeps CCM CCM41/9COMPACT MIC)	64
22509	Hi Wind Cover AA for Schoeps CMC MK41 (REMOTE CAPSULE)	64
<u>Sennheiser</u>		
22502	Hi Wind Cover 2 for Sennheiser MKH 20, 40, 50 , 406	66
22503	Hi Wind Cover3 for Sennheiser MKH 30, ME62 K6, MKE 44P	66
22504	Hi Wind Cover 4 for Sennheiser MKH 416, 418	68
22504	Hi Wind Cover 4 for Sennheiser MKH 60	68
22505	Hi Wind Cover 5 for Sennheiser ME66 K6	68
22505	Hi Wind Coverr 5 for Sennheiser ME80 K3U	68
22506	Hi Wind Cover 6 for Sennheiser MKH 70	68
22507	Hi Wind Cover 7 for Sennheiser ME67 K6	77
22508	Hi Wind Cover 8 for Sennheiser MKH 816	77
22503	Hi Wind Cover 3 for Sennheiser ME64 K6	66
<u>Shure</u>		
22503	Hi Wind Cover 3 for Shure SM 81	66
22508	Hi Wind Cover 8 for Shure SM89	77
<u>Sony</u>		
22503	Hi Wind Cover 3 for Sony ECM 959	66
22503	Hi Wind Cover 3 for Sony ECM-MS5	66
22504	Hi Wind Cover 4 for Sony ECM-670	68

22504	Hi Wind Cover 4 for Sony ECM 979	68
22504	Hi Wind Cover 4 for Sony ECM 999	68
22505	Hi Wind Cover 5 for Sony ECM-672	68
22507	Hi Wind Cover 7 for Sony C-74	77
Special	Special Hi Wind Cover for Sony C-76	
EXTENDED BALL GAG		
40106	Mono Extended Suspension	256
40107	Mono Extended Suspension MS	274
10605	Mono Extended Ball Gag Windshield	235
21509	Mono Extended Ball Gag Windjammer	132
22509	Mono Extended Ball Gag Hi Wind Cover	64
40215	Stereo Extended Suspension	265
10901	Stereo Extended Ball Gag Windshield	271
21628	Stereo Extended Ball Gag Windjammer	192
22627	Stereo Extended Ball Gag Hi Wind Cover	66
48426	XY / MS Mount (For remote capsule mics within stereo extended ball gag windshield)	250
BABY BALL GAG		
11001	20mm Baby Ball Gag Windshield	128
11002	22mm Baby Ball Gag Windshield	128
11003	25mm Baby Ball Gag Windshield	128
21801	Baby Ball Gag Windjammer	64
INVISION		
41101	INV-1	61
41102	INV-2	61
41103	INV-3	61
41104	INV-4	61
41105	INV-5	61
41106	INV-6	61
41107	INV-7	61

41108	INV-8	61
CONNBOXES		
16901	Connbox 1 (for most mono mics w/3-pin XLR)	132
16902	Connbox 2 (for longer mono mics with 3-pin XLR)	132
16903	Connbox 3 (for most stereo rigs w/3-pin XLRs)	188
16904	Connbox 4 (for single-shank stereo mics w/5-pin XLR)	188
16905	Connbox 5 (for remote capsule mics in Mono configuration w/Lemo Tail)	177
16906	Connbox 6 (for stereo remote pairs w/ Lemo Tails in Mono Ext. Susp)	314
16907	Connbox 7 (for stereo remote pairs w/ Lemo Tails in Stereo Ext. Susp. or XY configuration)	314
16913	Connbox 8 (or Schoeps CMIT-5U + CCM MS with XLR and Lemo Tail)	272
WINDSHIELD KIT		
86004	Windshield kit 1 (Modular 1 windshield, 1-module suspension, Modular 1 windjammer)	609
86003	Windshield kit 2 (Modular 2 windshield, 1 module suspension, Modular 2 windjammer)	609
86002	Windshield kit 3 (Modular 3 windshield, 1 module suspension, Modular 3 windjammer)	609
86001	Windshield kit 4 (Modular 4 windshield, 2 module suspension, Modular 4 windjammer)	641

86005	Windshield kit 5 (Modular 4 windshield, Extension 1, 2 module suspension, Modular 5 windjammer)	705
86006	Windshield kit 6 (Modular 4 windshield, Extension 2 (in separate box), 2-module suspension, Modular 6 windjammer)	705
86007	Windshield kit 7 (Modular 4 windshield, Extension 3 (in separate box), 3-module suspension, Modular 7 windjammer)	726
86008	Windshield kit 8 (Modular 4 windshield, Extension 4 (in separate box), 3-module suspension, Modular 8 windjammer)	726
86010	Full Windshield 10 Kit (Small Modular Suspension, Windshield 10 and Windjammer 10 in its own box)	609
S-SERIES KIT		
10301	S-series 300 Kit	387
10302	S-series 330 Kit	397
10303	S-series 375 Kit	407
10304	S-series 450 Kit	417
EXTENDED BALL GAG KITS		
86017	Mono Extended Ball Gag Kit (Suspension, Windshield and Windjammer)	624
86021	Mono Extended Ball Gag MS Kit (MS Suspension, Windshield and Windjammer	641
86022	Stereo Extended Ball Gag Kit (Stereo Suspension, Windshield and Windjammer)	729

LAVALIERE WINDJAMMER		
65501	Black Lavalier Windjammers	47
65502	Grey Lavalier Windjammers	47
65503	White Lavalier Windjammers	47
DUCK RAINCOVER		
214101	Duck Raincover	117
UNDERCOVERS		
65101	30 x Black Undercover Pack (incl 30 x Stickies)	10
65102	30 x Grey Undercover Pack (incl 30 x Stickies)	10
65103	30 x White Undercover Pack (incl 30 x Stickies)	10
65504	30 x Undercover Pack including 10 of Each Colour - Black, Grey & White (incl 30 x Stickies)	10
65104	100 x Black Undercover Pack (incl 100 x Stickies)	29
65105	100 x Grey Undercover Pack (incl 100 x Stickies)	29
65106	100 x White Undercover Pack (incl 100 x Stickies)	29
65107	Box of 25 Packs of 30 x Black Undercover Packs - 30 Adhesive Pads, 30 Fabric Covers Per Pack	243
65108	Box of 25 Packs of 30 x Grey Undercover Packs - 30 Adhesive Pads, 30 Fabric Covers Per Pack	243
65109	Box of 25 Packs of 30 x White Undercover Packs - 30 Adhesive Pads, 30 Fabric Covers Per Pack	243

65507	Box of 25 Packs of 30 x Undercover Packs Including 10 of Each Colour - Black, Grey & White - 30 Adhesive Pads, 30 Fabric Covers Per Pack	243
OVERCOVERS & STICKIES		
65505	Overcover Pack - 30 Adhesive Pads, 6 Reusable Fur Covers (2 of Each Colour - Black, Grey & White)	13
65506	Stickie Replacement Pack - 30 Adhesive Pads Per Pack Suitable for Undercovers & Overcovers	7
65508	Box of 25 Overcover Packs - 30 Adhesive Pads, 6 Reusable Fur Covers (2 of Each Colour - Black, Grey & White) Per Pack	316
65509	Box of 25 Stickie Replacement Packs - 30 Adhesive Pads Per Pack Suitable for Undercovers & Overcovers	170
SOFTIE WINDSHIELD		
AKG		
33311	5cm SH Softie w/MH mount & handle for AKG CK91/CK92/CK93 + SE 300B	312
33611	5cm SH Softie w/MH mount & b/adaptor for AKG CK91/CK92/CK93 + SE 300B	312
33011	5cm SH Softie front only for AKG CK91/CK92/CK93 + SE 300B	143
33701	SH mount only w/handle for AKG CK91/CK92/CK93 + SE 300B	169
34001	SH mount only w/boom adaptor for AKG CK91/CK92/CK93 + SE 300B	169
33312	5cm MH Softie w/MH mount & handle AKG CK 451/CK 460	312

33612	5cm MH Softie w/MH mount & b/adaptor AKG CK 451/CK 460	312
33012	5cm MH Softie front only for AKG CK 451/CK 460	143
33702	MH mount only w/handle for AKG CK 451/CK 460	169
34002	MH mount only w/boom adaptor for AKG CK 451/CK 460	169
33312	5cm MH Softie w/MH mount & handle for AKG CK61 C460B	312
33612	5cm MH Softie w/MH mount & b/adaptor for AKG CK61 C460B	312
33012	5cm MH Softie front only for AKG CK61 C460B	143
33702	MH mount only w/handle for AKG CK61 C460B	169
34002	MH mount only w/boom adaptor for AKG CK61 C460B	169
33312	5cm MH Softie w/MH mount & handle for AKG CK63 460	312
33612	5cm MH Softie w/MH mount & b/adaptor for AKG CK63 460	312
33012	5cm MH Softie front only for AKG CK63 460	143
33702	MH mount only w/handle for AKG CK63 460	169
34002	MH mount only w/boom adaptor for AKG CK63 460	169
33352	18cm MH Softie w/MH mount & handle for AKG C568EB	325
33652	18cm MH Softie w/MH mount & b/adaptor for AKG C568EB	325
33052	18cm MH Softie front only for AKG C568EB	156
33702	MH mount only w/handle for AKG C568EB	169
34002	MH mount only w/boom adaptor for AKG C568EB	169

33352	18cm MH Softie w/MH mount & handle for AKG CK68 ULS C460B RED	325
33652	18cm MH Softie w/MH mount & b/adaptor for AKG CK68 ULS C460B RED	325
33052	18cm MH Softie front only for AKG CK68 ULS C460B RED	156
33702	MH mount only w/handle for AKG CK68 ULS C460B RED	169
34002	MH mount only w/boom adaptor for AKG CK68 ULS C460B RED	169
33312	5cm MH Softie w/MH mount & handle for AKG CK98 SE300B	312
33612	5cm MH Softie w/MH mount & b/adaptor for AKG CK98 SE300B	312
33012	5cm MH Softie front only for AKG CK98 SE300B	143
33702	MH mount only w/handle for AKG CK98 SE300B	169
34002	MH mount only w/boom adaptor for AKG CK98 SE300B	169
33371	24cm SH Softie w/MH mount & handle for AKG CK8 451	338
33671	24cm SH Softie w/MH mount & b/adaptor for AKG CK8 451	338
33071	24cm SH Softie front only for AKG CK8 451	169
33701	SH mount only w/handle for AKG CK8 451	169
34001	SH mount only w/boom adaptor for AKG CK8 451	169
33372	24cm MH Softie w/MH mount & handle for AKG CK8 460	338
33672	24cm MH Softie w/MH mount & b/adaptor for AKG CK8 460	338
33072	24cm MH Softie front only for AKG CK8 460	169
33702	MH mount only w/handle for MKG CK8 460	169

34002	MH mount only w/boom adaptor for AKG CK8 460	169
33392	32cm MH Softie w/MH mount & handle for AKG CK68 ULS C460B	338
33692	32cm MH Softie w/MH mount & b/adaptor for AKG CK68 ULS C460B	338
33092	32cm MH Softie front only for AKG CK68 ULS C460B	169
33702	MH mount only w/handle for AKG CK68 ULS C460B	169
34002	MH mount only w/boom adaptor for AKG CK68 ULS C460B	169
<u>Audio Technica</u>		
33332	12cm MH Softie w/MH mount & handle for Audio Technica AT 4073	325
33632	12cm MH Softie w/MH mount & b/adaptor for Audio Technica AT 4073	325
33032	12cm MH Softie front only for Audio Technica AT 4073	156
33702	MH mount only w/handle for Audio Technica AT 4073	169
34002	MH mount only w/boom adaptor for Audio Technica AT 4073	169
33342	14cm MH Softie w/MH mount & handle for Audio Technica AT 835ST	325
33642	14cm MH Softie w/MH mount & b/adaptor for Audio Technica AT 835ST	325
33042	14cm MH Softie Front Only for Audio Technica AT 835ST	156
33702	MH mount only w/handle for Audio Technica AT 835ST	169
34002	MH mount only w/boom adaptor for Audio Technica AT 835ST	169
33332	12cm MH Softie w/MH mount & handle for Audio Technica AT 877	325
33632	12cm MH Softie w/MH mount & b/adaptor for Audio Technica AT 877	325

33032	12cm MH Softie front only for Audio Technica AT 877	156
33702	MH mount only w/handle for Audio Technica AT 877	169
34002	MH mount only w/boom adaptor for Audio Technica AT 877	169
33372	24cm MH Softie w/MH mount & handle for Audio Technica AT 835b	338
33672	24cm MH Softie w/MH mount & b/adaptor for Audio Technica AT 835b	338
33072	24cm MH Softie front only for Audio Technica AT 835b	169
33702	MH mount only w/handle for Audio Technica AT 835b	169
34002	MH mount only w/boom adaptor for Audio Technica AT 835b	169
33382	29cm MH Softie w/MH mount & handle for Audio Technica AT 815ST	338
33682	29cm MH Softie w/MH mount & b/adaptor for Audio Technica AT 815ST	338
33082	29cm MH Softie front only for Audio Technica AT 815ST	169
33702	MH mount only w/handle for Audio Technica AT 815ST	169
34002	MH mount only w/boom adaptor for Audio Technica AT 815ST	169
33342	14cm MH Softie w/MH mount & handle for Audio Technica AT 897	325
33642	14cm MH Softie w/MH mount & b/adaptor for Audio Technica AT 897	325
33042	14cm MH Softie Front Only for Audio Technica AT 897	156
33702	MH mount only w/handle for Audio Technica AT 897	169
34002	MH mount only w/boom adaptor for Audio Technica AT 897	169

33382	29cm MH Softie w/MH mount & handle for Audio Technica AT 4071a	338
33682	29cm MH Softie w/MH mount & b/adaptor for Audio Technica AT 4071a	338
33082	29cm MH Softie front only for Audio Technica AT 4071a	169
33702	MH mount only w/handle for Audio Technica AT 4071a	169
34002	MH mount only w/boom adaptor for Audio Technica AT 4071a	169
33392	32cm MH Softie w/MH mount & handle for Audio Technica AT 815b	338
33692	32cm MH Softie w/MH mount & b/adptr for Audio Technica AT 815b	338
33092	32cm MH Softie front only for Audio Technica AT 815b	169
33702	MH mount only w/handle for Audio Technica AT 815b	169
34002	MH mount only w/boom adaptor for Audio Technica AT 815b	169
Azden		
33352	18cm MH Softie w/MH mount & handle for Azden SG(M)-1X	325
33652	18cm MH Softie w/MH mount & b/adaptor for Azden SG(M)-1X	325
33052	18cm MH Softie front only for Azden SG(M)-1X	156
33702	MH mount only w/handle for Azden SG(M)-1X	169
34002	MH mount only w/boom adaptor for Azden SG(M)-1X	169
33312	5cm MH Softie w/MH mount & handle for Azden SG(M)-2X (Omni)	312
33612	5cm MH Softie w/MH mount & b/adaptor for Azden SG(M)-2X (Omni)	312
33012	5cm MH Softie front only for Azden SG(M)-2X (Omni)	143

33702	MH mount only w/handle for Azden SG(M)-2X (Omni)	169
34002	MH mount only w/boom adaptor for Azden SG(M)-2X (Omni)	169
33372	24cm MH Softie w/MH mount & handle SG(M)-2X (Cardiod capsule)	338
33672	24cm MH Softie w/MH mount & b/adaptor SG(M)-2X (Cardiod capsule)	338
33072	24cm MH Softie front only SG(M)-2X (Cardiod capsule)	169
33702	MH mount only w/handle SG(M)-2X (Cardiod capsule)	169
34002	MH mount only w/boom adaptor SG(M)-2X (Cardiod capsule)	169
Beyer		
33353	18cm LH Softie w/LH mount & handle for Beyer MCE 87vs	325
33653	18cm LH Softie w/MH mount & b/adaptor for Beyer MCE 87vs	325
33053	18cm LH Softie front only for Beyer MCE 87vs	156
33703	LH mount only w/handle for Beyer MCE 87vs	169
34003	LH mount only w/boom adaptor for Beyer MCE 87vs	169
33352	18cm MH Softie w/MH mount & handle for Beyer MC836	325
33652	18cm MH Softie w/MH mount & b/adaptor for Beyer MC736	325
33052	18cm MH Softie front only for Beyer MC736	156
33702	MH mount only w/handle for Beyer MC736	169
34002	MH mount only w/boom adaptor for Beyer MC736	169
33351	18cm SH Softie w/SH mount & handle for Beyer MC 716/726	325
33651	18cm SH Softie w/SH mount & b/adaptor for Beyer MC 716/726	325

33051	18cm SH Softie front only for Beyer MC 716/726	156
33701	SH mount only w/handle for Beyer MC 716/726	169
34001	SH mount only w/boom adaptor for Beyer MC716/726	169
33352	18cm MH Softie w/MH mount & handle for Beyer MC736	325
33652	18cm MH Softie w/MH mount & b/adaptor for Beyer MC736	325
33052	18cm MH Softie front only for Beyer MC736	156
33702	MH mount only w/handle for Beyer MC736	169
34002	MH mount only w/boom adaptor for Beyer MC736	169
33353	18cm LH Softie w/LH mount & handle for Beyer MCE 86 N (C) S	325
33653	18cm LH Softie w/MH mount & b/adaptor for Beyer MCE 86 N (C) S	325
33053	18cm LH Softie front only for Beyer MCE 86 N (C) S	156
33703	LH mount only w/handle for Beyer MCE 86 N (C) S	169
34003	LH mount only w/boom adaptor for Beyer MCE 86 N (C) S	169
<u>Dpa</u>		
33311	5cm SH Softie w/SH mount & handle for Dpa 4011	312
33611	5cm SH Softie w/SH mount & b/adaptor for Dpa 4011	312
33011	5cm SH Softie front only for Dpa 4011	143
33701	SH mount only w/handle for Dpa 4011	169
34001	SH mount only w/boom adaptor for Dpa 4011	169
<u>Neumann</u>		
33312	5cm MH Softie w/MH mount & handle for Neumann KM 184	312

33612	5cm MH Softie w/MH mount & b/adaptor for Neumann KM 184	312
33012	5cm MH Softie front only for Neumann KM KM 184	143
33702	MH mount only w/handle for Neumann KM KM 184	169
34002	MH mount only w/boom adaptor for Neumann KM 184	169
33352	18cm MH Softie w/MH mount & handle for Neumann KMR 81	325
33652	18cm MH Softie w/MH mount & b/adaptor for Neumann KMR 81	325
33052	18cm MH Softie front only for Neumann KMR 81	156
33702	MH mount only w/handle for Neumann KMR 81	169
34002	MH mount only w/boom adaptor for Neumann KMR 81	169
33382	29cm MH Softie w/MH mount & handle for Neumann KMR 82	338
33682	29cm MH Softie w/MH mount & b/adaptor for Neumann KMR 82	338
33082	29cm MH Softie front only for Neumann KMR 82	169
33702	MH mount only w/handle for Neumann KMR 82	169
34002	MH mount only w/boom adaptor for Neumann KMR 82	169
<u>Sanken</u>		
33351	18cm SH Softie w/SH mount & handle for Sanken CS-3	325
33651	18cm SH Softie w/SH mount & b/adaptor for Sanken CS-3	325
33051	18cm SH Softie front only for Sanken CS-3	156
33701	SH mount only w/handle for Sanken CS-3	169
34001	SH mount only w/boom adaptor for Sanken CS-3	169

<u>Schoeps</u>		
33311	5cm SH Softie w/SH mount & handle for Schoeps CMC SERIES	312
33611	5cm SH Softie w/SH mount & b/adaptor for Schoeps CMC SERIES	312
33011	5cm SH Softie from only for Schoeps CMC SERIES	143
33701	SH mount only w/handle for Schoeps CMC SERIES	169
34001	SH mount only w/boom adaptor for Schoeps CMC SERIES	169
33311	5cm SH Softie w/SH mount & handle for Schoeps CMC Series + CUT 1	312
33611	5cm SH Softie w/SH mount & b/adaptor for Schoeps CMC Series + CUT 1	312
33011	5cm SH Softie from only for Schoeps CMC Series + CUT 1	143
33701	SH mount only w/handle for Schoeps CMC Series + CUT 1	169
34001	SH mount only w/boom adaptor for Schoeps CMC Series + CUT 1	169
<u>Sennheiser</u>		
33313	5cm LH Softie w/LH mount & handle for Sennheiser MKH 20, 30, 40, 50	312
33613	5cm LH Softie w/LH mount & b/adaptor for Sennheiser MKH 20, 30, 40, 50	312
33013	5cm LH Softie front only for Sennheiser MKH 20, 30, 40, 50	143
33703	LH mount only w/handle for Sennheiser MKH 20, 30, 40, 50	169
34003	LH mount only w/boom adaptor for Sennheiser MKH 20, 30, 40, 50	169
33311	5cm SH Softie w/SH mount & handle for Sennheiser MKH 406	312
33611	5cm SH Softie w/SH mount & b/adaptor for Sennheiser MKH 406	312

33011	5cm SH Softie from only for Sennheiser MKH 406	143
33701	SH mount only w/handle for Sennheiser MKH 406	169
34001	SH mount only w/boom adaptor for Sennheiser MKH 406	169
33312	5cm MH Softie w/MH mount & handle for Sennheiser ME62/64 K6, MKE 44P	312
33612	5cm MH Softie w/MH mount & b/adaptor for Sennheiser ME62/64 K6, MKE 44P	312
33012	5cm MH Softie front only for Sennheiser ME62/64 K6, MKE 44P	143
33702	MH mount only w/handle for Sennheiser ME62/64 K6, MKE 44P	169
34002	MH mount only w/boom adaptor for Sennheiser ME62/64 K6, MKE 44P	169
33351	18cm SH Softie w/SH mount & handle for Sennheiser MKH 416, 418	325
33651	18cm SH Softie w/SH mount & b/adaptor for Sennheiser MKH 416, 418	325
33051	18cm SH Softie front only for Sennheiser MKH 416, 418	156
33701	SH mount only w/handle for Sennheiser MKH 416, 418	169
34001	SH mount only w/boom adaptor for Sennheiser MKH 416, 418	169
33353	18cm LH Softie w/LH mount & handle for Sennheiser MKH 60	325
33653	18cm LH Softie w/LH mount & b/adaptor for Sennheiser MKH 60	325
33053	18cm LH Softie front only for Sennheiser MKH 60	156
33703	LH mount only w/handle for Sennheiser MKH 60	169
34003	LH mount only w/boom adaptor for Sennheiser MKH 60	169

33352	18cm MH Softie w/MH mount & handle for Sennheiser ME66 K6	325
33652	18cm MH Softie w/MH mount & b/adaptor for Sennheiser ME66 K6	325
33052	18cm MH Softie front only for Sennheiser ME66 K6	156
33702	MH mount only w/handle for Sennheiser ME66 K6	169
34002	MH mount only w/boom adaptor for Sennheiser ME66 K6	169
33352	18cm MH Softie w/LH mount & handle for Sennheiser ME80K3U	325
33652	18cm MH Softie w/LH mount & b/adaptor for Sennheiser ME80K3U	325
33052	18cm MH Softie front only for Sennheiser ME80K3U	156
33702	MH mount only w/handle for Sennheiser ME80K3U	169
34002	MH mount only w/boom adaptor for Sennheiser ME80K3U	169
33383	29cm LH Softie w/LH mount & handle for Sennheiser MKH 70	338
33683	29cm LH Softie w/LH mount & b/adaptor for Sennheiser MKH 70	338
33083	29cm LH Softie front only for Sennheiser MKH 70	169
33703	LH mount only w/handle for Sennheiser MKH 70	169
34003	LH mount only w/boom adaptor for Sennheiser MKH 70	169
33382	29cm MH Softie w/MH mount & handle for Sennheiser ME67 K6	338
33682	29cm MH Softie w/MH mount & b/adaptor for Sennheiser ME67 K6	338
33082	29cm MH Softie front only for Sennheiser ME67 K6	169

33702	MH mount only w/handle for Sennheiser ME67 K6	169
34002	MH mount only w/boom adaptor for Sennheiser ME67 K6	169
<u>Sony</u>		
33352	18cm MH Softie w/SH mount & handle for Sony ECM-670	325
33652	18cm MH Softie w/SH mount & b/adaptor for Sony ECM-670	325
33052	18cm MH Softie front only for Sony ECM-670	156
33702	MH mount only w/handle for Sony ECM-670	169
34002	MH mount only w/boom adaptor for Sony ECM-670	169
33353	18cm LH Softie w/MH mount & handle for Sony ECM-672	325
33653	18cm LH Softie w/MH mount & b/adaptor for Sony ECM-672	325
33053	18cm LH Softie front only for Sony ECM-672	156
33703	LH mount only w/handle for Sony ECM-672	169
34003	LH mount only w/boom adaptor for Sony ECM-672	169
CAMERA MOUNTED SOFTIES		
<u>Canon</u>		
33023	10cm LH Softie front for Canon XL-1, XL-1S	156
34323	10cm Short Hair LH Softie front for Canon XL-1, XL-1S	156
<u>Ikegami</u>		
33022	10cm MH Softie front for Ikegami MC-11	156
34322	10cm Short Hair MH Softie front for Ikegami MC-11	156
33031	12cm SH Softie front for Ikegami HL-V55/MC10/HLV9	156

34331	12cm Short Hair SH Softie front for Ikegami HL-V55/MC10/HLV9	156
33032	12cm MH Softie front for Ikegami HL DV-7W/HLV 77/DNS-201W/MC 230	156
34332	12cm Short Hair MH Softie front for Ikegami HL DV-7W/HLV 77/DNS-201W/MC 230	156
JVC		
33021	10cm SH Softie front for JVC DY-500	156
34321	10cm Short Hair SH Softie front for JVC DY-500	156
33052	18cm MH Softie front for JVC DY-70U	156
34352	18cm Short Hair MH Softie front for JVC DY-70U	156
33022	10cm MH Softie front for JVC MV-P615U (on board camera mic)	156
34322	10cm Short Hair MH Softie front for JVC MV-P615U (on board camera mic)	156
Panasonic		
33031	12cm SH Softie front for Panasonic DV 200/DVC200	156
34331	12cm Short Hair SH Softie front for Panasonic DV 200/DVC200	156
33032	12cm MH Softie front for Panasonic AJD-700/AJD-800/AJD-910	156
34332	12cm Short Hair MH Softie front for Panasonic AJD-700/AJD-800/AJD-910	156
33042	14cm MH Softie front for Panasonic WM-L130	156
34342	14cm Short Hair MH Softie front for Panasonic WM-L130	156
Sony		
33023	10cm LH Softie front for Sony DNW7/DVW400	156
34323	10cm Short Hair LH Softie front for Sony DNW7/DVW400	156

33023	10cm LH Softie front for Sony DNW-90WSP/ DNW-9-NSP/DNW 90P/DNW-90SX/ DNW-790	156
34323	10cm Short Hair LH Softie front for Sony DNW-90WSP/DNW-9-NSP/DNW 90P/ DNW-90SX/DNW-790	156
33023	10cm LH Softie front for Sony DVW-700P/ 700WSP/707/709/ DVW-600	156
34323	10cm Short Hair LH Softie front for Sony DVW-700P/700WSP/707/709/ DVW-600	156
33023	10cm LH Softie front for Sony HD-905P	156
34323	10cm Short Hair LH Softie front for Sony HD-905P	156
33031	12cm SH Softie front for Sony UVW-100, BVP-550	156
34331	12cm Short Hair SH Softie front for Sony UVW-100, BVP-550	156
33032	12cm MH Softie front for Sony DXC-D30P	156
34332	12cm Short Hair MH Softie front for Sony DXC-D30P	156
33032	12cm MH Softie front for Sony DSR-130P/ DSR200/DSR300	156
34332	12cm Short Hair MH Softie front for Sony DSR-130P/DSR200/DSR300	156
33032	12cm MH Softie front for Sony DSR-250/DSR- PD150	156
34332	12cm Short Hair MH Softie front for Sony DSR-250/DSR-PD150	156
33032	12cm MH Softie front for Sony BVP-570/ BVP950	156
34332	12cm Short Hair MH Softie front for Sony BVP-570/BVP950	156
33033	12cm LH Softie front for Sony BVW, BVP-5, BVP-7	156
34333	12cm Short Hair LH Softie front for Sony BVW, BVP-5, BVP-7	156
33042	14cm MH Softie front for Sony DXC-637	156

34342	14cm Short Hair MH Softie front for Sony DXC-637	156
33053	18cm LH Softie front for Sony BVP-537	156
34352	18cm Short Hair LH Softie front for Sony BVP-537	156
SMOOTHIES		
<u>Banana Smoothies (Yellow)</u>		
39211	5cm Small Hole Banana	73
39212	5cm Medium Hole Banana	73
39213	5cm Large Hole Banana	73
39311	10cm Small Hole Banana	73
39312	10cm Medium Hole Banana	73
39313	10cm Large Hole Banana	73
39411	12cm Small Hole Banana	73
39412	12cm Medium Hole Banana	73
39413	12cm Large Hole Banana	73
39511	14cm Small Hole Banana	73
39512	14cm Medium Hole Banana	73
39513	14cm Large Hole Banana	73
39611	18cm Small Hole Banana	73
39612	18cm Medium Hole Banana	73
39613	18cm Large Hole Banana	73
<u>Blackberry Smoothies (Black)</u>		
39221	5cm Small Hole Blackberry	73
39222	5cm Medium Hole Blackberry	73
39223	5cm Large Hole Blackberry	73
39321	10cm Small Hole Blackberry	73
39322	10cm Medium Hole Blackberry	73
39323	10cm Large Hole Blackberry	73
39421	12cm Small Hole Blackberry	73
39422	12cm Medium Hole Blackberry	73

39423	12cm Large Hole Blackberry	73
39521	14cm Small Hole Blackberry	73
39522	14cm Medium Hole Blackberry	73
39523	14cm Large Hole Blackberry	73
39621	18cm Small Hole Blackberry	73
39622	18cm Medium Hole Blackberry	73
39623	18cm Large Hole Blackberry	73
<u>Blueberry Smoothies (Blue)</u>		
39231	5cm Small Hole Blueberry	73
39232	5cm Medium Hole Blueberry	73
39233	5cm Large Hole Blueberry	73
39331	10cm Small Hole Blueberry	73
39332	10cm Medium Hole Blueberry	73
39333	10cm Large Hole Blueberry	73
39431	12cm Small Hole Blueberry	73
39432	12cm Medium Hole Blueberry	73
39433	12cm Large Hole Blueberry	73
39531	14cm Small Hole Blueberry	73
39532	14cm Medium Hole Blueberry	73
39533	14cm Large Hole Blueberry	73
39631	18cm Small Hole Blueberry	73
39632	18cm Medium Hole Blueberry	73
39633	18cm Large Hole Blueberry	73
<u>Lime Smoothies (Green)</u>		
39241	5cm Small Hole Lime	73
39242	5cm Medium Hole Lime	73
39243	5cm Large Hole Lime	73
39341	10cm Small Hole Lime	73
39342	10cm Medium Hole Lime	73
39343	10cm Large Hole Lime	73
39441	12cm Small Hole Lime	73
39442	12cm Medium Hole Lime	73
39443	12cm Large Hole Lime	73
39541	14cm Small Hole Lime	73
39542	14cm Medium Hole Lime	73

39543	14cm Large Hole Lime	73
39641	18cm Small Hole Lime	73
39642	18cm Medium Hole Lime	73
39643	18cm Large Hole Lime	73
<u>Strawberry Smoothies (Red)</u>		
39251	5cm Small Hole Strawberry	73
39252	5cm Medium Hole Strawberry	73
39253	5cm Large Hole Strawberry	73
39351	10cm Small Hole Strawberry	73
39352	10cm Medium Hole Strawberry	73
39353	10cm Large Hole Strawberry	73
39451	12cm Small Hole Strawberry	73
39452	12cm Medium Hole Strawberry	73
39453	12cm Large Hole Strawberry	73
39551	14cm Small Hole Strawberry	73
39552	14cm Medium Hole Strawberry	73
39553	14cm Large Hole Strawberry	73
39651	18cm Small Hole Strawberry	73
39652	18cm Medium Hole Strawberry	73
39653	18cm Large Hole Strawberry	73
<u>Smoothie Windjammers (Dark Grey)</u>		
21709	5cm Smoothie Windjammer	63
21710	10cm Smoothie Windjammer	63
21711	12cm Smoothie Windjammer	63
21712	14cm Smoothie Windjammer	63
21713	18cm Smoothie Windjammer	63